



**Fermi National Accelerator Laboratory
Batavia, IL 60510**

MQTM TRIM MAGNET INCOMING INSPECTION TRAVELER

**Reference Drawing (s):
ME-351349**

Project # / Task #: 20/20.22.1.1.8.1		Job #: 197
Released by: Bob Jensen		Magnet / Device Series: MQTM
Date: 9/18/03 2:37:48 PM		Scan Pages: 9
Prepared by: M. Cullen		
Title	Signature	Date
TD / E&F Process Engineering	Bob Jensen <small>Bob Jensen / Designee</small>	6/19/03
TD / E&F Assembly	Dan Smith <small>Dan Smith / Designee</small>	6/19/03
TD / E&F Project Engineer	Alexander Makarov <small>Alexander Makarov / Designee</small>	6/19/03
TD / E&F Project Manager	John Carson <small>John Carson / Designee</small>	6/19/03

Revision Page

Revision	Step No.	Revision Description	TRR No.	Date
None	N/A	Initial Release	N/A	11/7/02
A	4.1	Only perform complete magnet electrical inspection.	1560	6/17/03

Ensure appropriate memos and specific instructions are placed with the traveler before issuing the sub traveler binder to production.

1.0 General Notes


- 1.1 White (Lint Free) Gloves (Fermi stock 2250-1800) or Surgical Latex Gloves (Fermi stock 2250-2494) shall be worn by all personnel when handling all product parts after the parts have been prepared/cleaned.
- 1.2 All steps that require a sign-off shall include the Technician/Inspectors first initial and full last name.
- 1.3 No erasures or white out will be permitted to any documentation. All incorrectly entered data shall be corrected by placing a single line through the error, initial and date the error before adding the correct data.
- 1.4 All Discrepancy Reports issued shall be recorded in the left margin next to the applicable step.
- 1.5 All personnel performing steps in this traveler must have documented training for this traveler and associated operating procedures.
- 1.6 Personnel shall perform all tasks in accordance with current applicable ES&H guidelines and those specified within the step.
- 1.7 Cover the magnet assembly with green Herculite (Fermi stock 1740-0100) when not being serviced or assembled.

2.0 Parts Kit List

- 2.1 No Part Kit required.


3.0 Magnet Acceptance

- 3.1 Update DSR Keywords (Location [IB2], Location Verified Date & Status [awaiting E&F completion]) and make entry regarding work to be performed.


Lead Person

9/17/03
Date

- 3.2 Verify that the 2 digits of the serial number stamped on the magnet matches the last 2 digits of the serial number at the bottom of this traveler. Record any serial numbers visible on the magnet. Visually inspect magnet for damage. If any out of the ordinary conditions exists notify your supervisor.


Lead Person

9-19-03
Date

4.0 Initial Coil/Magnet Inspection

4.1 Perform an Electrical.


Magnet	Equipment Serial Number	Limit	Actual Measurement	Pass	Fail	Out of Tolerance
Resistance	32-1005	1.5 to 1.8 Ω	1.66 Ω	✓		
LS @ 1 KHz	84619	65 to 75 mH	70.1 mH	✓		
Q @ 1 KHz		40-50	41.2	✓		
LS @ 100 Hz		Reference Test Only Not Subject to Acceptance Criteria	70.3 mH			
Q @ 100 Hz			25.0			
100 Volt Ring	P62000			✓		
Hipot Coil to Core	A60504	< 5 μ A @ 500 V	< .1	✓		


D. Gae
Inspector

9-19-03
Date

5.0 Close Out


- 5.1 Stencil the serial number and weight (Lbs.) 1" characters centered on side of the magnet.


Note(s):**The serial numbers should match serial number at the bottom of this traveler.**EXAMPLESERIAL NUMBER
MAGNET WEIGHT

Technician(s)

Date


- 5.2 Update DSR Keywords (Location, Location Verified Date & Status) and make entry regarding work performed. Change Status to Ready to use



Lead Person

Date

- 5.3 Affix the completed Generic Magnet Identification Labels (MA-318490) (Qty. 1) on the magnet on the aisle side. Affix a completed Generic Magnet Identification Label (MA-318490) to this page.

 Fermi National Accelerator Laboratory Technical Division						
MQTM Trim Quadrupole						
Serial No:	MQTM131-0		Drawing No:	ME-351349		Magnet Weight: 226 Lbs
	DC Resistance:	Ls @ 1kHz:	Q @ 1kHz:	Ls @ 100Hz:	Q @ 100Hz:	HiPot Coil To Core @ 500VDC
Upper Coil:	N/A mΩ	N/A mH	N/A	N/A mH	N/A	N/A μA
Lower Coil:	N/A mΩ	N/A mH	N/A	N/A mH	N/A	N/A μA
Full Magnet:	1.66 Ω	70.1 mH	41.2	70.3 mH	25.0	<.1 μA
Previous Serial No(s):						
Remarks: Mfg MM/YY by Moscow Radio Technical Institute, Moscow, Russia.					Date Completed: 9/22/2003	

Partially Completed
Generic Magnet Identification Label (MA-318490)

Bob Zluz
Inspector

9/22/03
Date

6.0 Production Complete


- 6.1 Process Engineering verify that the Traveler is accurate and complete. This shall include a review of all steps to ensure that all operations have been completed and signed off. Ensure that all Discrepancy Reports, Nonconformance Reports, Repair/Rework Forms, Deviation Index and dispositions have been reviewed by the Responsible Authority for conformance before being approved.

Comments:


Process Engineering/Designlee

9/22/03
Date

10:19:22 Fri Sep 19, 2003



	State	Volts/Div	Position	Cplg	BW Lim	Inv	Probe
Chan 1	On	20.00 V	0.000 V	DC	Off	Off	10:1
Chan 2	Off	100.0mV	0.000 V	DC	Off	Off	1:1

	Mode	Main Time/Div	Main Delay	Time Ref	Delayed Time/Div	Delayed Delay
Horizontal	Normal	1.000ms/	0.000 s	Left	-----	-----

Trigger Mode	Source	Level	Holdoff	Slope	Couplg	Reject	NoiseRej
Normal	Ch 1	3.750 V	200.0ns	Pos	DC	HF	On

Display Mode: Normal

Traveler	333703 RA
Step #	4.1
Magnet Serial Number	MGT M131-0
Technician	D. Gae
Page Count	1 of 1